

Forclean - Accessories

INDICATION IN CASING



INDICATION IN CASING

S1: Type

111.02: Indication in casing

S2: Single-circuit single-sensor indicator

SA1: single-circuit single-sensor indicator

S3: Number of pieces of indicator SA1

n: arbitrary number of pieces of indicator

1, 2, - n; ... arbitrary number of pieces

S4: Single-circuit double-sensor indicator

SA2 : single-circuit double-sensor indicator

S5: Number of pieces of indicator SA2

n: arbitrary number of pieces of indicator

1, 2, - n; ... arbitrary number of pieces

S6: Double-circuit single-sensor indicator SB1

SB1: double-circuit single-sensor indicator SB1

S7: Number of pieces of indicator SB1

n: arbitrary number of pieces of indicator

1, 2, - n; ... arbitrary number of pieces

S8: Double-circuit double-sensor indicator SB2

SB2 : double-circuit double-sensor indicator

S9: Number of pieces of indicator SB2

n: arbitrary number of pieces of indicator

1, 2, - n; ... arbitrary number of pieces

S10: Output auxiliary contact

S: output auxiliary contact for light

Z: output auxiliary contact for lock

S11: Connection of output terminal OK

OK1 : Ucc is connected (against earthing) to output terminal (OK) when activated*

OK2: output terminal (OK) is connected to "GD" when activated

OK3 : output terminal is disconnected from Ucc when activated

OK4: output terminal is disconnected from "GD" when activated

* Activation means mode Y (Z), or the opening of the respective door.

S12: Time delay

P: without time delay

T: time delay

cat. no. 111.02

Forclean - Accessories

INDICATION IN CASING